


# MKE-5-IS SCALE SYSTEM SCHEMATIC – CONFIGURATION #1

Approved Intrinsically Safe (IS) Display Indicator (battery operated only) connected to approved IS Platform.



## HAZARDOUS AREA



### NOTES:

- 1) No components are required in the **SAFE** Area. All equipment reside in the **HAZARDOUS** Area during operation.
- 2) Batteries must be recharged in the **SAFE** Area. The IS Indicator does not recharge batteries.